


NOTES:

1. INSTALL BACKFLOW PREVENTER AS REQUIRED BY LOCAL CODES AND HEALTH DEPARTMENT. VERIFY LOCAL REQUIREMENTS PRIOR TO INSTALLATION.
2. INSTALL FREEZE PROTECTION JACKET AND CAGE. SEE CITY STANDARD DETAIL LSD-17 FOR CAGE DETAIL.
3. REFER TO CITY STANDARD DETAIL LSD-14 FOR ALL MATERIALS

			CITY OF FREMONT STANDARD DETAILS				DATE APPROVED BY CITY COUNCIL 12/13/11		
							RESOLUTION NO. 2006-31		
									
1	MISC REVISIONS	9/09	CITY STANDARD IRRIGATION BACKFLOW PREVENTER UNIT						
APPR	REVISED	DATE							
REVISIONS							CITY ENGINEER		
FILE NO. LSD-16.DWG		SCALE 1" = 1'-0"		DRAWN PM/MM	CHECKED RER	DATE NOV. 2005	DWG NO. LSD-16		16 of 27